

FIG. 1






FIG.2



0002202000000000

FIG.3






FIG.4

FIG.5




FIG.6 PRIOR ART

EXAMPLE OF CONTROL IN SINGLE CLOCK (IN LDA & STA CONTINUOUS COMMAND)





FIG. 7 EXAMPLE OF SOLUTION BY INSERTING NOP



CONTROL METHOD OF CPU CORE IN PRESENT EMBODIMENT




FIG.8





FIG.9






FIG.11




FIG.12

81

